
About this guide

This document describes the installation of ISDN BRI line and trunk applications for Meridian 1 system options 21, 21E, 51, 51C, 61, 61C, 71, 81, and 81C.

It describes where and how to install ISDN BRI network and peripheral equipment cards, and explains how to connect the digital subscriber loops (DSLs) to the Meridian 1 for line and trunking applications.

Note: Not all features and services are available in all markets. For example, ISDN BRI trunking is not supported in the United States. For more information, please contact your local Northern Telecom representative.

Applicability of this guide

The intended audience of this guide is all craftspersons charged with installing ISDN BRI.

How this guide is organized

This publication has been organized in the following sections.

Preinstallation preparation explains how to verify that the site is prepared for ISDN BRI equipment installation and how to unpack and inspect the equipment and take inventory.

Installing ISDN BRI hardware for line and trunk applications describes procedures for installing ISDN BRI equipment for line and trunking.

Related documents

ISDN BRI:

- ISDN Basic Rate Interface Product Description 553-3901-100
- ISDN Basic Rate Interface Administration 553-3901-300
- ISDN Basic Rate Interface Acceptance Testing 553-3901-330
- ISDN Basic Rate Interface Maintenance 553-3901-500

Note: This guide does not contain information specific to Meridian 1 system Option 11. This may be found in the *Option 11 ISDN BRI administration and maintenance* (553-3011-311).